


How to remove the faucet cover

- 1 Pull the transparent ring toward you.




- 2 Then ,pull on the ring in a angle and keep the pressure downward

- 3 Slide the cover toward you



- 4 Position the lever on the actual faucets .
** They must be straight so that the push button when press down catches the faucet lever. **



Before placing back the cover, you could try by pressing on levers to see if water is coming out correctly.

- 5 Put back the cover , slide it into place.

